



RINGBROTHERS

E4829 Hwy 14 • Spring Green, WI 53588 • 608.588.7399 • www.ringbrothers.com • info@ringbrothers.com

20699-7111 1969 Camaro Billet Headlamp Trim Ring Kit Installation Instructions

Thank you for purchasing Ringbrothers direct replacement headlamp trim rings. We take pride in every part we build.

Parts list:

- 2 - 6061 T6 Billet headlamp trim rings
- 8 - 8-32 button head cap screws

Tools required:

- 1/8" drill bit and drill
- 3/32" allen wrench

Remove headlamp and bucket.

With bucket removed from car turn upside down, use 1/8" drill bit to drill out four factory rivets from pot metal trim ring.

Discard factory trim ring and place Ringbrothers trim ring on bucket in factory location, re-attach using four of the supplied 8-32 button head cap screws.

If you have any questions please call Ringbrothers at 608-588-7399.

Thank you!
Mike & Jim Ring
Ringbrothers
