



E4829 Hwy 14 • Spring Green, WI 53588 • 608.588.7399 • www.ringbrothers.com • info@ringbrothers.com

99000-9415 Universal Carbon Fiber Hood Scoop

Thank you for purchasing a Ringbrothers Universal Carbon Fiber Hood Scoop.

Preparation instructions for carbon fiber:

1. Clean scoop with acetone
 2. Hand sand with 320 grit sand paper—DO NOT over sand!
 3. Clean scoop with acetone again
 4. Brush on 4 to 5 coats of clear coat with a foam brush
 5. Once clear coat is completely dry, sand clear like you would primer
 6. Once smooth, clean once more with acetone and then spray with clear coat to desired finish.
-